


Size guide


Cresto Energy harnesses



The size guide is designed to simplify the choice of size of our harnesses. We are aware that not everyone can identify with the people in the guide below and therefore there is also a table with tolerances for the different dimensions, A, B, C and DD. Follow the instructions at the bottom right if you need to take measurements.



		A	B	C	DD
ENERGY PRO 1136	XS	96-136 cm	75-96 cm	46-61 cm	29 cm
	S	96-136 cm	84-113 cm	46-61 cm	36 cm
	M	96-136 cm	94-123 cm	46-66 cm	46 cm
	L	96-146 cm	104-133 cm	48-73 cm	56 cm
	XL	96-146 cm	114-143 cm	48-78 cm	66 cm
ENERGY PRO-WIND 1136-Wind	S	96-136 cm	84-113 cm	46-61 cm	36 cm
	M	96-136 cm	94-123 cm	46-66 cm	46 cm
	L	96-146 cm	104-133 cm	48-73 cm	56 cm
	XL	96-146 cm	114-143 cm	48-78 cm	66 cm
ENERGY PRO+ 1135-TO	S	107-165 cm	74-117 cm	50-75 cm	50 cm
	M	117-175 cm	84-127 cm	52-82 cm	60 cm
	L	120-185 cm	94-137 cm	52-85 cm	70 cm




A - Distance diagonally from left waist to right shoulder.
 B - Waist circumference.
 C - Thigh circumference.
 DD - Distance between the D-rings fixation points in the back support.

Storleksguide


Cresto Energy Selar



Storleksguiden är till för att förenkla valet av storlek på våra selar. Vi är medvetna om att alla inte kan identifiera sig med personerna i guiden nedan och därför finns även en tabell med toleranser för de olika måtten, A, B, C och DD. Följ instruktionerna längst ner till höger om du behöver ta mått.



		A	B	C	DD
ENERGY PRO 1136	XS	96-136 cm	75-96 cm	46-61 cm	29 cm
	S	96-136 cm	84-113 cm	46-61 cm	36 cm
	M	96-136 cm	94-123 cm	46-66 cm	46 cm
	L	96-146 cm	104-133 cm	48-73 cm	56 cm
	XL	96-146 cm	114-143 cm	48-78 cm	66 cm
ENERGY PRO-WIND 1136-Wind	S	96-136 cm	84-113 cm	46-61 cm	36 cm
	M	96-136 cm	94-123 cm	46-66 cm	46 cm
	L	96-146 cm	104-133 cm	48-73 cm	56 cm
	XL	96-146 cm	114-143 cm	48-78 cm	66 cm
ENERGY PRO+ 1135-TO	S	107-165 cm	74-117 cm	50-75 cm	50 cm
	M	117-175 cm	84-127 cm	52-82 cm	60 cm
	L	120-185 cm	94-137 cm	52-85 cm	70 cm



A - Måttet mäts diagonalt från vänster midja till höger axel.

B - Midjemått omkrets.

C - Lärmått omkrets.

DD - Avstånd mellan D-ringarnas fixeringspunkter i ryggstödet.